

LCD Digital Color TV



Sony Customer Support

U.S.A.: www.sony.com/tvsupport
Canada: www.sony.ca/support

United States

Canada

1.800.222.SONY

1.877.899.SONY

Please Do Not Return the Product to the Store

KDL-32L4010

© 2009 Sony Corporation
Printed in U.S.A.




2 Initial Setup

After you finish connecting your TV, you need to run **Initial Setup**. The **Initial Setup** screen appears when you turn on your TV for the first time.


- 1
- Press to turn on the TV.

The **Initial Setup** screen will appear.

Press to highlight the desired language, then press to select it.




- 2
- Connect cable or antenna, and then select **Yes** to start **Auto Program**. Your TV will detect the type of signal and will start to search for available channels.



-
- If you have both cable and antenna available, please connect your cable first.
 - IMPORTANT: You must perform Auto Program after your cable or antenna is connected. If you cancel Auto Program before completion, some channels may not be available.**

- 3
- Follow the help text provided on the screen to run **Auto Program**. When the **Auto Program** is complete press to finish the **Auto Program** process.



If you did not follow the **Initial Setup** instructions the first time you turned on your TV, see your Operating Instructions and look for the **Auto Program** in the **Channel** menu.

To Do List

When you have completed the **Initial Setup**, consider doing the following:

- Adjust Closed Captions (CC)

Label Inputs/Skip Inputs

Show/Hide Channels

Adjust the Speakers

For more details, see your TV **BRAVIA** Operating Instructions.

1 Your New BRAVIA® LCD HDTV

Congratulations! Your new TV BRAVIA® will open the door to a “fantastic High Definition (HD) experience”. This guide will help you get the most out of your new High Definition TV.

Follow these steps before you turn on your TV BRAVIA:

- Register online at: <http://productregistration.sony.com> (from U.S.A.)
<http://www.SonyStyle.ca/registration> (from Canada)
- Make sure you have taken all the accessories out of the box.
- Install 2 AA batteries (supplied separately) in your remote control.
- You must decide whether you want your TV on the wall, or place it on the Table-Top stand. Sony Wall-Mount Brackets have been designed to provide optimum adjustment.
- Leave 2 3/8 inches (6 cm) of free space behind your TV for proper ventilation.

You must get HD programming to experience the stunning detail of HDTV.

- The quality of the image you see on your BRAVIA can only be as high as the quality of the signal it is displaying.
- Contact your cable or satellite provider to upgrade your service to HD. Receive over-the-air HD broadcasts with an HD-quality antenna (www.antennaweb.org) and discover the wealth of entertainment now available on super-high-resolution Blu-ray Disc™.

To learn more about HDTV, visit:

U.S.A.: <http://www.sony.com/HDTV>

Canada: <http://www.SonyStyle.ca/hd>

Connecting to Your TV

Your BRAVIA TV must be properly connected to components such as sound system and cable or satellite box.

- Turn off and unplug all components before making connections.
- Do not turn on the TV until connection setup is completed.
- See reverse side of this poster for sample connection diagrams.

INPUT Connector	VIDEO Connection	AUDIO	High or Standard Definition Quality				
			HD		SD		PC
			1080i	720p	480p	480i	
HDMI 1 HDMI 2	 HDMI connection*	HDMI cable carries both video and audio signals. (*When HDMI is connected to DVI with an adapter, a separate audio L/R is necessary.)	●	●	●	●	●
COMPONENT 1 COMPONENT 2	 Component connection	 Audio L/R	●	●	●	●	
VIDEO 1	 S VIDEO connection	 Audio L/R				●	
VIDEO 1 VIDEO 2	 Composite video connection	 Audio L/R				●	

3 Watching TV

Select the source of content

In order to watch cable, satellite, direct TV, watch a video, a DVD, a Blu-ray Disc, or to connect your TV to a PC, you need to choose the proper input with your remote control.


- Select on your remote control and then select **External Inputs**.
The list of external inputs will be displayed; or
- Press to display the **External Inputs** on the screen and select your desired option.

Adjust the shape and aspect ratio of the screen

High-definition and standard-definition signals are transmitted with different aspect ratios (the width-to-height ratio of the image). Most HDTV signals use a wide screen aspect ratio of 16:9. The 16:9 will fill your TV BRAVIA screen, maintaining a crisp, clear, vivid picture.



Most standard definition signals use a boxy 4:3 aspect ratio. When a 4:3 image is displayed on an HDTV, you will see black bars on the sides. The picture quality may not be as sharp as with HD sources.




- Press on your remote control to choose the **Wide Mode** setting of your preference.

Customize sound and picture quality


You may choose the proper sound and picture for the content you are watching on your TV.

- Press on your remote control and select the **Picture** or **Sound** menu. Then choose the appropriate setting for your content.
- Use on your remote control to quickly adjust the picture quality.
- See your TV BRAVIA Operating Instructions for more information.


Basic HD connection with A/V receiver



Basic Connection for Home Theater System




Required Cable Types for Connection



Notes on the Connections:

- Your TV is equipped with two HDMI inputs, connect your incoming signal source (HD Cable Box, HD Satellite Receiver, or DVD) with an HDMI or component video for the best possible picture quality.
- If the equipment has a DVI and not a HDMI connector, use a HDMI to DVI cable or adapter to connect the DVI output to either HDMI IN 1 or HDMI IN 2 input, and connect the audio jacks to the AUDIO (L/R) jacks below the HDMI IN 2. (DVI connector is for video signals only. The Audio jacks provide support for the audio.)
- **PIP** functions require Cable/Antenna connection.
- When receiving High-Definition content signal by over-the-air antenna, it is best to use the HD antenna.
- When using a DVI-to-HDMI cable, make sure to connect the DVI side first.

Basic Connection for SD VCR/DVD



PC Connection

